

How to specify a Temperature Transmitter

THIS IS WHAT WE NEED TO KNOW:

- Type of Sensor Input
- Wiring Configuration
- Din Rail or Head Mounting
- Output Signal - ma/HART/Profibus
- Hazardous Area Classification
- Programme range
- Failure Mode Settings
- Power Supply Details
- Relay Requirements

